


## Video Goggles IWEAR



## Technical Data

### I – Box Contents



The box contains :

1. Video Goggles and Cable
2. Cleaning tissue
3. Sun Screen

### II – Comfort and Adjustability

The video goggles IWEAR have settings to hold around the head. It is necessary to remove the little rubber pads on each side to enlarge the goggles branches gap.

This pair of goggle allows you to adjust the viewing angle to line up with your eyes. Hold the display and move it towards the top or the bottom to line it with your eyes.





**ADJUST YOUR GOGGLES IN ORDER TO WORK WITH CONFIDENCE.**

### III - Display

A command pad is located on the cable, this allows access to the brightness and contrast settings.



Use the key « MAIN » to select the brightness function then use the key + and – to adjust the brightness.



The contrast settings works like the brightness control : Use the Key « MAIN » to select « Contrast ». Use the keys + et – to adjust the brightness.

### IV - Cleaning


These goggles have been designed to minimize and ease the maintenance. Abrasive product may not be used, paper towels and handkerchifs can scratch the surface of your IWAR lenses. To clean the lenses, steam the lense and wipe it with a microfiber tissue delivered with the goggle set.

### V – Security measures

Observe security measures when using the IWEAR in order to reduce the risks of damage on the device or the user.

1. Immersive video, when used on a TV monitor, cinema screen or video goggles can have side effects on the user : Eye fatigue, perceptive residual effects, disorientation. Do frequent pause in order to reduce these effects, as recommended for other devices such as computers. If your eyes show signs of fatigue or are dry or in presence of any other symptom written above, stop working and make a pause.

2. Always be conscious of what and who is around you. This product will plunge you in the ultrasound image, and you may forget what is around you and potential threats on the farm such as unpredictable animal behaviour.



3. Do not use this product close to stairs or other locations where you could tumble and fall.
  4. Do not drop, hit or shake the product, such actions may damage it.
  5. Do not pull, twist or knock the cable. Do not hang the product on its cable. To unplug the product, pull on the connector, not on the cables.
-